

powered by BUREAU




Installation Guide


MOTTO XL

PRODUCT SPECS

External size: W2200*D2186*H2346
Unit: mm



CIRCUIT DIAGRAM



US/CAN


AU/UK/UNI

READ BEFORE START

Thanks for choosing our product, please mind these tips below during the installation:

1. Two people should be prepared for the installation.
2. Please use cushioning material for stacking parts after unboxing in case of damaging floor or product.
3. Please don't scratch any piece with a sharp tool.
4. Please check all listed tools are prepared.
5. Please check the space for installation is sufficient.
6. Please follow the step by number to build.


PRODUCT INTRODUCTION























PART LIST


Numbering rules		Y-00 Tools				A-00 Aluminim				C-00 Glass				G-00 Seal Strip			
A-00	Aluminim	Code	Description	Qty.	Preview	Code	Description	Qty.	Preview	Code	Description	Qty.	Preview	Code	Description	Qty.	Preview
B-00	Carbon Plastic Panel	Y-01	Torx Wrench	1		A-01	Arc Beam-Upper(L)	1		C-02	Door	1		G-01-04	Adhesive strip -Vertical edge	4	
C-00	Glass	Y-02	Rubber Mallet	1		A-02	Arc Beam-Upper(R)	1		C-01	Glass Wall -Front(L)	1		G-11	Adhesive strip Front-door (L)	1	
D-00	Metal Hardware	Y-03	Plastic Crowbar	1		A-03	Arc Beam-lower(L)	1		C-03	Glass Wall -Front(R)	1		G-12	Adhesive strip Front-door (R)	1	
E-00	Upholstery	Y-04	Allen Wrench	1		A-04	Arc Beam-lower(R)	1		C-04	Glass Wall -Rear(L)	1		G-13	Adhesive strip Front-upper (L)	1	
F-00	Electronics	Y-05	Vacuum Handle	2		A-05	Front Frame-Upper	1		C-05	Glass Wall -Rear(M)	1		G-14	Adhesive strip Front-under (L)	1	
G-00	Seal Strip					A-06	Rear Frame-Upper	1		C-06	Glass Wall -Rear(R)	1		G-15	Adhesive strip Front-under (R)	1	
H-00	Accessory					A-07	Front Frame-Lower	1		D-00 Metal hardware				G-16	Adhesive strip Front-under (R)	1	
Y-00	Tool					A-08	Rear Frame-Lower	1		D-01	Door Closer	1		G-17	Adhesive strip Rear Upper (L)	1	
						A-09	Front Frame (L)	1		D-02	Door Lock	1		G-18	Adhesive strip Rear Upper (B)	1	
						A-10	Rear Frame (L)	1		E-00 Upholstery				G-07	Corner Seal Block	8	
						A-11	Front Frame (R)	1		E-11-14	Acoustic Panel(L)	4		G-21-22	Acrylic Seal Strip	2	
						A-12	Rear Frame (R)	1		E-21-24	Acoustic Panel(R)	4		G-09	D-shaped Rubber Seal (L)	2	
						A-13	Door Column(L)	1		E-31	Acoustic Ceiling Panel(L)	1		G-10	D-shaped Rubber Seal (2)	2	
						A-14	Door Column(R)	1		E-32	Acoustic Ceiling Panel(R)	1		H-00 Accessory			
						A-15-22	Corner Cover	8		E-51	Carpet	1		H-01	Power Cord	1	
						A-23	Lamp Trough	2		F-00 Electronics				H-02	Screw Sticker	28	
						A-24	Door Column Upper	1		F-06	Switch Panel	1		H-03	Emergency Hammer	1	
						A-25	Door Column Upper	1		F-07	Fan Switch Panel	1		H-04	Bottom Plate Pad	14	
						B-00 Carbon Plastic Panel				F-09	IR Motion Sensor	1					
						B-11-17	Side Panel (L)	7		F-10	Ambient Light	1					
						B-21-27	Side Panel (R)	7									
						B-31-37	Top Panel	7									
						B-41-47	Bottom Panel	7									
						B-51-53	Reinforced Floor Panel	3									

ASSEMBLY INSTRUCTIONS






ST-06 TABLE



Part List		
Code	Description	Qty.
1	Desk Panel	1
2	Main Pillar	1
3	Main Pillar Board	1
4	Frame Kit 1	2
5	Frame Kit 2	1
6	Pillar Holder	1
7	Screw M6*45mm	10
8	Screw M6*15mm	4
9	Screw M6*25mm	2
10	Screw ST4*30mm	3
11	Allen Wrench 3.0	1
12	Allen Wrench 4.0	1
13	Crosshead Screwdriver	1
14	Screw M5*10mm	2
15	Screw M5*12mm	2

ST-04 TABLE



Part list		
Code	Description	Qty.
1	Table Top	1
2	Table Bracket	2
3	Wire Hole Cover	1
4	Screw M6*25mm	6
5	Screw M6*35mm	6
6	Allen Wrench	1

CAUTIONS

Warning - Do not use any electronics exceeding 1000W in case of overload. - Do not use the product if the ventilation channels are blocked. - Keep the ventilation channels free from foreign objects and debris. - Protect all electric hardware from damage, which could cause electrical leakage. - Do not modify the product in case of a short circuit.	- Do not scratch glass with any sharp object. - Do not smoke or light fires in the pod. - Always set the caster to the non-moving state. - Disconnect the power cord from the power outlet before starting any cleaning, maintenance, or disassembly procedures. - Do not use the product if the ventilation is not functioning.	- Do not climbing on top of the product or place any load on the top of the product. - Do not use this product in an environment with oxygen concentration lower than 20%. - Do not slam the door. - Do not use this product outdoors.	Maintenance & Care - Please contact authorized personnel for repairing, don't operate without official instruction. - Do not put anything heavier than 10kg on the desk. - Cut off the power immediately if any malfunction occurs.	Problem & Solution - In case of no power from the power outlets and the fan or lamp doesn't work. - Make sure the power cord is plugged in properly. - Check if the fuse is burnt out. - Check that the wire terminal is firmly connected to the wire following the correct label.
---	--	--	--	--